

# PRODUCT DATA SHEET

# Sika® Sanisil®

# SILICONE SEALANT FOR SANITARY APPLICATIONS



#### **DESCRIPTION**

Sika® Sanisil® is a 1-part, non-sag, silicone sealant with long term resistance to fungus and mildew.

#### **USES**

- Sanitary or other sealing applications where mildew and fungus resistance is required
- Domestic kitchens
- For interior and exterior use

# **CHARACTERISTICS / ADVANTAGES**

- Good long term fungus and mildew resistance
- Very good adhesion to most non-porous substrates
- Good UV and weathering resistance
- Solvent free (acc. to TRGS 610)
- High elasticity and flexibility

# **APPROVALS / CERTIFICATES**

 CE Marking and Declaration of Performance to EN 15651-3 - Sealants for non-structural use in joints in buildings - Sealants for sanitary

# **PRODUCT INFORMATION**

Composition	Acetoxy silicone			
Packaging	300 ml cartridge: 12 cartridges per box			
Colour	Colour range to be defined by local sales organisation.			
Shelf life	18 months from date of production	18 months from date of production		
Storage conditions	•	The product must be stored in original, unopened and undamaged sealed packaging in dry conditions at temperatures between +5 °C and +25 °C. Always refer to packaging.		
Density	~1,00 kg/l	(ISO 1183-1)		
Product Declaration	EN 1565-3: S XS1			
TECHNICAL INFORMAT	ION			
Shore A Hardness	~20 (after 28 days)	(ISO 868)		
Tensile Strength	~1,8 N/mm²	(ISO 8339)		
Secant Tensile Modulus	~0,35 N/mm² at 100% elongation (+23 °C)	(ISO 8339)		
Elongation at Break	~550 %	(ISO 37)		
Elastic Recovery	> 90 %	(ISO 7389)		

#### Product Data Sheet

**Sika® Sanisil®**November 2019, Version 03.01
02051403000000011

Tear Propagation Resistance	~2,6 N/mm	(ISO 34)
Movement Capability	±20 %	(ISO 9047)
Service Temperature	-40 °C / +100 °C	
Joint Design	The joint dimensions must be designed to suit the movement capability of the sealant. For joint widths more than 10 mm and less than 20 mm, a joint depth of 10 mm is recommended.  For larger joints, contact Sika Technical Services for additional information	

#### APPLICATION INFORMATION

Consumption	Joint width [mm]	Joint depth [mm	Joint length [m] per 300 ml		
	10	10	3,0		
	15	10	2,0		
	20	10	1,5		
	Consumption depends on the roughness and absorbency of the substraction These figures are theoretical and do not allow for any additional mater due to surface porosity, surface profile, variations in level or wastage e				
Backing Material	Use closed cell, polyethylene foam backing rod.				
Sag Flow	< 1 mm (20 mm profile, +23 °C)		(ISO 7390)		
Ambient Air Temperature	+5 °C min. / +40 °C max.				
Substrate Temperature	+5 °C min. / +40 °C max., min. 3 °C above dew point temperature				
Curing Rate	~3,0 mm/24 hours (+	~3,0 mm/24 hours (+23 °C / 50 % r.h.) (CQP* 049-2) *Sika Corporate Quality Procedure			
Skinning time	~25 min (+23 °C / 50	% r.h.)	(CQP 019-1)		

#### **APPLICATION INSTRUCTIONS**

# SUBSTRATE PREPARATION

The substrate must be sound, clean, dry and free of all contaminants such as dirt, oil, grease, old sealants and poorly bonded paint coatings which could affect adhesion of the sealant. The substrate must be of sufficient strength to resist the stresses induced by the sealant during movement.

Removal techniques such as wire brushing, grinding, grit blasting or other suitable mechanical tools can be used.

All dust, loose and friable material must be completely removed from all surfaces using suitable equipment before application of any activators, primers or sealant

Sika® Sanisil® adheres without primers and/or activators

For optimum adhesion, joint durability and critical, high performance applications such as joints on multistorey buildings, highly stressed joints, extreme weather exposure or water immersion / exposure. The following priming and/or pre-treatment procedures must be followed:

#### Non-porous substrates

Aluminium, anodised aluminium, stainless steel, PVC, galvanised steel, powder coated metals or glazed tiles. Slightly roughen surface with a fine abrasive pad.

Clean and pre-treat using Sika® Aktivator-205 applied with a clean cloth.

Before sealing, allow a waiting time of > 15 minutes (< 6 hours).

Other metals, such as copper, brass and titanium-zinc, clean and pre-treat using Sika® Aktivator-205 applied with a clean cloth. After a waiting time of > 15 minutes (< 6 hours). Apply Sika® Primer-3 N applied by brush. Before sealing, allow a waiting time of > 30 minutes (< 8 hours)

PVC has to be cleaned and pre-treated using Sika® Primer-215 applied with a brush. Before sealing, allow a waiting time of > 30 minutes (< 8 hours).

Glass must be cleaned with Isopropanol before application

#### **Porous substrates**

Porous substrates must be primed using Sika® Primer-3 N applied by brush. For more details such as application and flash-off times, refer to the most recent Product Data Sheet of the respective pre-treatment product.

Before sealing, allow a waiting time of > 30 minutes (< 8 hours).

Adhesion tests on project specific substrates must be performed and procedures agreed with all parties before full project application.

For more detailed advice and instructions contact Sika Technical Services.

#### Product Data Sheet

Sika® Sanisil®

November 2019, Version 03.01 020514030000000011



Note: Primers and activators are adhesion promoters and not an alternative to improve poor preparation / cleaning of the joint surface. Primers also improve the long term adhesion performance of the sealed joint.

#### MIXING

1-part ready to use

#### **APPLICATION METHOD / TOOLS**

Strictly follow installation procedures as defined in method statements, application manuals and working instructions which must always be adjusted to the actual site conditions.

#### Masking

It is recommended to use masking tape where neat or exact joint lines are required. Remove the tape within the skinning time after finishing.

#### **Joint Backing**

After the required substrate preparation, insert a suitable backing rod to the required depth.

# **Priming**

If required, prime the joint surfaces as recommended in substrate preparation. Avoid excessive application of primer to avoid causing puddles at the base of the joint.

#### **Application**

Sika® Sanisil® is supplied ready to use.

Prepare the end of the foil pack or cartridge, insert into the sealant gun and fit the nozzle. Extrude Sika® Sanisil® into the joint ensuring that it comes into full contact with the sides of the joint and avoiding any air entrapment.

#### **Finishing**

As soon as possible after application, sealant must be firmly tooled against the joint sides to ensure adequate adhesion and a smooth finish.

Use a compatible tooling agent to smooth the joint surface. Water can be used. Do not use tooling products containing solvents.

#### **CLEANING OF EQUIPMENT**

Removal of fresh remnants from tools and application equipment can be carried out using Sika® Remover-208 immediately after use. Hardened material can only be removed mechanically. For cleaning skin, use Sika® Cleaning Wipes-100.

#### **FURTHER INFORMATION**

Sika Pre-treatment Sealing and Bonding Chart

#### IMPORTANT CONSIDERATIONS

- Sika® Sanisil® C cannot be overpainted.
- Colour variations may occur due to the exposure in service to chemicals, high temperatures and/or UV radiation (especially with white colour shade). This effect is aesthetic and does not adversely influence the technical performance or durability of the product.
- Do not use to seal joints in and around swimming pools.
- Do not use on bituminous substrates, natural rubber,

- EPDM rubber or on any building materials which might leach oils, plasticisers or solvents that could degrade the sealant.
- Do not us in totally confined spaces as it requires atmospheric moisture to cure.
- Sika® Sanisil® is not recommended for porous substrates, such as concrete, stone, marble and granite. Staining from plasticiser migration may occur when used on these substrates. Preliminary trials must be carried out to check if the substrate experiences staining before full project application.
- Do not use where physical or abrasion exposure is likely to occur, structural glazing and insulated glazing or food contact applications. Contact Sika Technical Services for advice on alternative products.
- Do not use for medical or pharmaceutical uses.
- Acetic acid released during curing can cause the corrosion of mirror silver and sensitive metals such as cooper, brass and lead.
- Do not use on alkaline surfaces such as concrete, plaster, render and brick.

#### **BASIS OF PRODUCT DATA**

All technical data stated in this Product Data Sheet are based on laboratory tests. Actual measured data may vary due to circumstances beyond our control.

#### LOCAL RESTRICTIONS

Please note that as a result of specific local regulations the performance of this product may vary from country to country. Please consult the local Product Data Sheet for the exact description of the application fields.

# **ECOLOGY, HEALTH AND SAFETY**

For information and advice on the safe handling, storage and disposal of chemical products, users shall refer to the most recent Safety Data Sheet (SDS) containing physical, ecological, toxicological and other safety-related data.

#### **LEGAL NOTES**

The information, and, in particular, the recommendations relating to the application and end-use of Sika products, are given in good faith based on Sika's current knowledge and experience of the products when properly stored, handled and applied under normal conditions in accordance with Sika's recommendations. In practice, the differences in materials, substrates and actual site conditions are such that no warranty in respect of merchantability or of fitness for a particular purpose, nor any liability arising out of any legal relationship whatsoever, can be inferred either from this information, or from any written recommendations, or from any other advice offered. The user of the product must test the product's suitability for the intended application and purpose. Sika reserves the right to change the properties of its products. The proprietary rights of third parties must be observed. All orders are accepted subject to our current terms of sale and delivery. Users must always



Sika® Sanisil®

November 2019, Version 03.01 020514030000000011



refer to the most recent issue of the local Product Data Sheet for the product concerned, copies of which will be supplied on request.

#### Sika Hellas ABEE

15 Protomagias Str. 14568 Kryoneri Attica-Greece Tel.: +30 210 8160 600 Fax: +30 210 8160 606 www.sika.gr | sika@gr.sika.com





Product Data Sheet Sika® Sanisil® November 2019, Version 03.01 020514030000000011 SikaSanisil-en-GR-(11-2019)-3-1.pdf

